

---

A Die Sets

---

B Precision Ground Plates and Flat Bars

---

C Lifting and Clamping Devices

---

D Guide Elements

---

E Ground Precision Components

---

F Springs

---

**G Elastomer-Bars, -Sheets, -Sections**

FIBROFLEX® and FIBROELAST®-Sheets and -Profiles

---

H FIBRO Chemical Tooling Aids

---

J Peripheral Equipment


---

K Slide Units

---

L Standard Parts for Mould Making

---



# Elastomer

- Bars
- Sheets
- Sections

The occurrence of small batch lots in the press shop generally makes the more expensive dies of conventional design unadvisable – and it is in this sector in particular that FIBROFLEX® Forming Elastomers can offer economical alternatives.

Over many years in the past, rubber was used for metal forming work, mostly with indifferent results because of insufficient mechanical resilience and susceptibility to damage by workshop lubricants.

FIBROFLEX®, a polyurethane elastomer of very special properties, represents a synthetic material of significant advantages over all conventional rubber substances. It provides:

- highest resistance to rupturing
- outstanding elastic properties
- extensive life span when used correctly
- good thermal resilience
- inertness to all lubricants used in metal forming operations.

To the designer of forming- and shearing dies, FIBROFLEX® offers highly attractive solutions to many a tooling problem – as for instance the completion in one operation of intricate return flanges etc. Special mention ought to be made here of the specific suitability this elastomer exhibits in the forming of delicate surface-coated or surface-refined sheet metal.

The quite outstanding elastic properties of FIBROFLEX® have made it an almost indispensable material in toolrooms everywhere and also in many sectors of general engineering. Its numerous successful uses comprise bumper stops, strippers, ejector- and forming pads, spring elements as well as noise suppression applications.

FIBROFLEX® Forming Elastomers, available in three Shore hardnesses to suit different conditions, are supplied in a comprehensive range of sections hollow and solid, also in sheet form of many dimensions.

Intended as suggestions for the solution of forming problems, a number of illustrated application examples are contained in this catalogue. Further detailed information on elastomer tooling can be found in our free publication “Elastomers in Sheet Metal Forming and the Toolroom”, which we shall gladly mail to interested customers.















**FIBROFLEX\***

accurate parts  
to customers  
specifications

\*Polyurethan

**Contents**

	Page		Page
Technical Data on FIBROFLEX®	G6-G7	2511.3. FIBROELAST® Sheets	G12
	251. FIBROFLEX® Sheets and Pads	G8	
	252. FIBROFLEX® Square Sections	G8	
	250. FIBROFLEX® Channel Sections	G9	
	255. FIBROFLEX® Hollow Square Sections	G9	
	253. FIBROFLEX® Round Sections	G10	
	254. FIBROFLEX® Hollow Round Sections	G10	
	256. FIBROFLEX® Equilateral Triangle Sections	G11	
	257. FIBROFLEX® Equilateral Hollow Triangle Selections	G11	
			
			
			
			
		2531.4. FIBROELAST® Round Sections	G13
		2541.4. FIBROELAST® Hollow Round Sections	G13
		2450. Shock Absorbing Washers FIBROFLEX®	G9
		Example of FIBROFLEX® Application: Combination Blanking-, Embossing and Forming Die	G17-G19
		Blanking and forming with FIBROFLEX®-Elastomers	G21-G27

# Technical Data on FIBROFLEX® Forming Elastomer

## Physical Properties:

FIBROFLEX® Type	DIN	5	6	7
Shore-A-Hardness	53505	80	90	95
Density g/cm <sup>3</sup>	53479	1,07	1,11	1,14
max. deformation in %		35	30	25
Impact resistance value N/cm (ASTM D 470)		124	150	270
Elongation to tear in %	53504	490	430	380
Tearing strength in N/mm <sup>2</sup>	53504	34,4	38	44,8
Working temperature, max. °C		+70	+70	+70
Embrittlement temperature °C		below -68	below -68	below -63
Modulus of elasticity N/mm <sup>2</sup>		38	70	133
Electric puncture strength (per mm thickness)			400 Volt	
Rebound elasticity %	53512	58	42	40
At 100 % elongation MPa	53504	5,5	5,6	12,4
At 300 % elongation MPa	53504	10,3	15,2	29,6
Coefficient of friction of FIBROFLEX®			dry 0,35 any Shore hardness wet 0,25 any Shore hardness	
Tensile strength MPa	53504	34	38	45
Elongation %	53504	490	430	380
Tear strength kN/m	53515	36	42	58
Abrasion resistance mm <sup>3</sup>	53516	48	32	41
Torsional stiffness at 24°C in MPa		17,9	17,9	19,8
Compressive Set				
70h/22°C in %	53517	not available	not available	not available
Compressive Set				
70h/22°C in % – Methode B –	53517	25	27	36
Resistance to Sea Water (saline) approximately 6 months				
Resistivity (direct current) at			24° C 4,8 × 10 <sup>11</sup> 70° C 3,8 × 10 <sup>10</sup> 100° C 2,3 × 10 <sup>10</sup>	
Coefficient of expansion			0 up to -36° C = 1,43 <sup>-4</sup> 0 up to 24° C = 1,01 <sup>-4</sup> 25 up to 100° C = 0,95 <sup>-4</sup>	

## Guide Lines for the Machining of FIBROFLEX®:

FIBROFLEX® Forming Elastomers can be machined on ordinary machine tools and with conventional cutters.  
A keen cutting edge is mandatory.

FIBROFLEX® Type	5	6	7
Identification Colour	green	yellow	red
Shore-A-Hardness	80	90	95
Sawing	V <sub>c</sub> = approx. 1600 m/min.		
Circular saw, carbide-tipped, coarse toothed			
Rake angle 25°-30°			
Clearance angle 12°-15°			
Drilling	V <sub>c</sub> = approx. 30 m/min.		
Turning	V <sub>c</sub> = approx. 140 m/min.		
Rake angle 25°			
Clearance angle 12°-15°			
Milling	V <sub>c</sub> = approx. 100 m/min.		
Rake angle 25°			
Clearance angle 12°-15°			

Please note that we can supply form parts, required in larger quantities, in the ready-cast condition. Enquiries are invited.

V<sub>c</sub> = cutting speed

**Temperature Resistance**

FIBROFLEX® can be used safely at temperatures up to +70 °C. FIBROFLEX® will retain most of its flexibility at temperatures as low as –62 °C. A gradual increase in rigidity sets in below –18 °C. Resistance to thermal shock is excellent.

**Resistance to Oxygen and Ozone**

No traceable influences are incurred at normal atmospheric concentrations.

**Resistance to Aging**

Aging shows no discernable effects in conditions of normal ambient temperatures and generally constant environmental surroundings.

**Water Resistance**

FIBROFLEX® exhibits outstanding long-term stability under exposure to water of up to +50 °C. Swelling and/or destructive influences remain absent.

This typical resistance against hydrolysis is characteristic for the specific molecular structure of the elastomer.

Water-Oil emulsions present no problems either.

These are clear advantages of FIBROFLEX® over other polyurethane elastomer structures.

**Resistance to oil, chemicals, and solvents**

FIBROFLEX® is presenting an excellent resistance to oil and solvents and is, particularly, suiting applications in connection with lubricating oil and fuel.

Typical data of chemical resistance are shown in the following table.

**Table No 1 – Resistance to some Chemicals**


Diesel Fuel	○
Mineral Fats, acc. to additives	+ to –
Vegetabilic Fats	+
Animal Fats	+
Petrol (free of alcohols)	○
Mineral Oils – depending on additives	+
Paraffin	+ to –
Rape Seed Oil	+
Lubrificants on Mineral Oil Basis	○
Soap Emulsions	–
Vaseline	+
Water at +95 °C	–
Water at +20 °C	+ to ○

- + resistant = can be used
- conditionally resistant = conditional use
- not resistant = not recommended

Please note that blended oils and fats may have detrimental influence due to their various additives. In order to eliminate any risk, it is recommended to test the elastomer under exposure to any specific oily and/or fatty substance. Such tests ought to be run for several weeks.

**FIBROFLEX®-Sheets and Pads**  
**FIBROFLEX®-Square Sections**


251.  
252.



251.		a × b		a × b		Part III		a × b		a × b	
Order No	Part I	Part II	s	250 × 250	250 × 500	a × b	500 × 500	500 × 1000	1000 × 1000		
251.	.	.	1-7	●	●	●	●	●	●		
			increasing in steps of 1 mm								
			008. 8	●	●	●	●	●	●		
			010. 10	●	●	●	●	●	●		
			012. 12	●	●	●	●	●	●		
			015. 15	●	●	●	●	●	●		
			020. 20	●	●	●	●	●	●		
			025. 25								
			30-80 increasing in steps of 10 mm								

**Execution:**  
 FIBROFLEX® is avail. in 3 Shore hardnesses:  
 .5. = 80 Shore A = colour: Green  
 .6. = 90 Shore A = colour: Yellow  
 .7. = 95 Shore A = colour: Red  
 Further technical data: see pages G 6 – G 7

**Ordering Code (example):**  
 FIBROFLEX® Sheet = 251.  
 Hardness 95 Shore-A = 7.  
 s = 1 mm = 001.  
 a × b = 500 × 500 mm = 0500.0500  
 Order No = 251.7.001.0500.0500



252.		a × b			a × b			a × b					
Order No	a × b	250	500	1000	a × b	250	500	1000	a × b	250	500	1000	
252.	008.008.▽			●	252.	020.020.▽			252.	060.080.	●	●	●
	008.015.▽			●		020.030.▽				080.080.	●	●	●
	008.025.▽			●		020.040.▽				080.100.	●	●	●
	008.050.▽			●		020.050.▽				100.100.	●	●	●
	010.010.▽			●		022.022.	●	●		100.125.	●	●	●
	010.015.▽			●		025.025.▽				100.180.	●	●	●
	010.025.▽			●		025.040.▽				125.125.	●	●	●
	010.050.▽			●		025.060.▽							
	012.012.▽			●		025.080.▽							
	012.020.▽			●		030.030.	●	●					
	012.030.▽			●		040.040.▽							
	012.050.▽			●		040.060.	●	●					
	015.015.	●	●	●		045.045.	●	●					
	015.025.▽			●		050.050.	●	●					
	015.040.▽			●		050.180.	●	●					
	015.050.▽			●		060.060.	●	●					

▽ = machined dimensional edge

**Execution:**  
 FIBROFLEX® is available in 3 Shorehardnesses:  
 .5. = 80 Shore A = colour: Green  
 .6. = 90 Shore A = colour: Yellow  
 .7. = 95 Shore A = colour: Red  
 Further technical data : see pages G 6 – G 7




# FIBRO

250.  
255.

## FIBROFLEX® Channel Sections FIBROFLEX® Hollow Square Sections

250.



250.

Order No				Part III	
Part I	Part II	a × b	a <sub>1</sub> × b <sub>1</sub>	l <sub>1</sub> 250	l <sub>1</sub> 500
250.	.050.050.	50 × 50	35 × 20	●	●
	050.075.	50 × 75	35 × 30	●	●
	075.100.	75 × 100	50 × 40	●	●
	100.200.	100 × 200	60 × 120	●	●

### Execution:

FIBROFLEX® is avail. in 3 Shore hardnesses:



.5.	= 80 Shore A = colour: Green
.6.	= 90 Shore A = colour: Yellow
.7.	= 95 Shore A = colour: Red

Further technical data: see pages G 6 – G 7

### —Ordering Code (example):

FIBROFLEX® Channel Section	= 250.
Hardness 90 Shore A	= 6.
a × b = 50 × 50 mm	= 050.050.
l <sub>1</sub> = 250 mm	= 0250
Order No	= 250.6.050.050.0250

255.



255.


Order No					Part III			Execution:
Part I	Part II	a × b	a <sub>1</sub> × b <sub>1</sub>	d <sub>1</sub>	l <sub>1</sub> 250	l <sub>1</sub> 500	l <sub>1</sub> 1000	
255.	.040.060.	40 × 60	20 × 35		●	●	●	FIBROFLEX® is avail. in 3 Shore hardnesses: .5. = 80 Shore A = colour: Green .6. = 90 Shore A = colour: Yellow .7. = 95 Shore A = colour: Red Further technical data: see pages G 6 – G 7
	045.045.	45 × 45		20	●	●	●	
	050.050.	50 × 50		25	●	●	●	
	050.180.	50 × 180	20 × 120		●	●	●	
	060.060.	60 × 60		30	●	●	●	
	060.080.	60 × 80	30 × 50		●	●	●	
	080.080.	80 × 80		40	●	●	●	
	080.100.	80 × 100	40 × 60		●	●	●	
	100.100.	100 × 100	50 × 50		●	●	●	
	100.125.	100 × 125	50 × 70		●	●	●	
	100.180.	100 × 180	50 × 123		●	●	●	
	125.125.	125 × 125	75 × 75		●	●	●	

### Ordering Code (example):

FIBROFLEX® Hollow Square Section	= 255.
Hardness 80 Shore A	= 5.
a × b = 50 × 50 mm	= 050.050.
l <sub>1</sub> = 500 mm	= 0500
Order No	= 255.5.050.050.0500

**FIBROFLEX®-Round Sections**  
**FIBROFLEX®-Hollow Round Sections**

253.  
254.



**253.**

Order No	Part I	Part II	d <sub>1</sub>	330	Part III l <sub>1</sub>	500	1000
253.□.002			2	●			
003			3				●
004			4				●
005			5				●
006			6				●
007			7				●
008			8				●
010			10				●
012			12				●
016			16	●			
020			20		●		
025			25		●		
032			32		●		
040			40		●		
050			50		●		
063			63		●		
080			80		●		
100			100		●		
125			125		●		
140			140		●		
150			150		●		
160			160		●		
180			180		●		
200			200		●		

**Ordering Code (example):**

FIBROFLEX® Round Section	=	253.
Hardness 95 Shore-A	=	7.
d <sub>1</sub> = 40 mm	=	040
Order No	=	253.7.040

**254.**

Order No	Part I	Part II	d <sub>1</sub>	d <sub>2</sub>	330	Part III l <sub>1</sub>	500
254.□.016			16	6,5	●		
020			20	8,5			●
025			25	10,5			●
032			32	13,5			●
040			40	13,5			●
050			50	17,0			●
063			63	17,0			●
080			80	21,0			●
100			100	21,0			●
125			125	27,0			●
140			140	50,0			●
150			150	50,0			●
160			160	50,0			●
180			180	50,0			●
200			200	50,0			●

**Ordering Code (example):**

FIBROFLEX® Hollow Round Section	=	254.
Hardness 90 Shore-A	=	6.
d <sub>1</sub> = 50 mm	=	050
Order No	=	254.6.050


**Execution:**

FIBROFLEX® is avail. in 3 Shore hardnesses:  
 □.5. = 80 Shore A = colour: Green  
 □.6. = 90 Shore A = colour: Yellow  
 □.7. = 95 Shore A = colour: Red  
 Further technical data: see pages G 6 – G 7

# FIBRO

256.  
257.

FIBROFLEX® Triangular-Sections  
FIBROFLEX® Hollow Triangular-Sections



256.		Part III			
Order No		$l_1$	$l_1$		
Part I	Part II	250	500		
256.	□.035.	●	●		
	050.	●	●		
	080.	●	●		

**Ordering Code (example):**  
FIBROFLEX® Equilateral Triangle-Section = 256.  
Hardness 90 Shore-A = 6.  
size  $b = 35 \text{ mm}$  = 035.  
 $l_1 = 500 \text{ mm}$  = 0500  
Order No = 256.6.035.0500

257.		Part III			
Order No		$d_1$	$l_1$	$l_1$	
Part I	Part II	b	250	500	
257.	□.035.	35	●	●	
	050.	50	●	●	
	080.	80	●	●	

**Ordering Code (example):**  
FIBROFLEX® Equilateral Hollow Triangle-Section = 257.  
Hardness 90 Shore-A = 6.  
size  $b = 50 \text{ mm}$  = 050.  
 $l_1 = 250 \text{ mm}$  = 0250  
Order No = 257.6.050.0250


**Execution:**  
FIBROFLEX® is avail. in 3 Shore hardnesses:  
□□□.5. = 80 Shore A = colour: Green  
□□□.6. = 90 Shore A = colour: Yellow  
□□□.7. = 95 Shore A = colour: Red  
Further technical data: see pages c 6 – c 7

**FIBROELAST® Sheets**

**2511.3.**



2511.3.



2511.3.

Order No		s	Part III			
Part I	Part II		a × b 250 × 250	a × b 250 × 500	a × b 500 × 500	a × b 500 × 1000
2511.3.		1-7	●	●	●	●
		increasing in steps of 1 mm				
	008.	8	●	●	●	●
	010.	10	●	●	●	●
	012.	12	●	●	●	●
	015.	15	●	●	●	●

**Ordering Code (example):**

FIBROELAST® Sheet	=	2511.
Hardness 65 Shore A	=	3.
s = 15 mm	=	015.
a = 250 mm	=	0250.
b = 500 mm	=	0500
Order No	=	2511.3.015.0250.0500

**Material:**  
Polyester-based polyurethane  
Hardness 65 Shore A

**Colour:**  
White

**Note:**  
Other sheet thicknesses available upon request.



**Physical properties:**

Shore hardness A	65
100% modulus of elasticity (MN/m <sup>2</sup> )	2,4
300% modulus of elasticity (MN/m <sup>2</sup> )	4,6
Tensile strength (MN/m <sup>2</sup> )	26
Elongation (%)	550
Tear resistance (kN/m)	46
Permanent set (%)70°C	45
Rebound elasticity (%)	58
Maximum deformation (%)	40

# FIBRO

2531.4.  
2541.4.

# FIBROELAST®-Round Sections FIBROELAST®-Hollow Round Sections



**2531.4.**

Order No		d1	l1	
Part I	Part II		330	500
2531.4.	016	16	●	
	020	20		●
	025	25		●
	032	32		●
	040	40		●
	050	50		●
	063	63		●
	080	80		●
	100	100		●
	125	125		●

**Ordering Code (example):**

FIBROELAST® Round Section	=	2531.
Hardness 70 Shore A	=	4.
d1 = 40 mm	=	040
Order No	=	2531.4.040

**2541.4.**

Order No		d1	d2	l1	
Part I	Part II			330	500
2541.4.	016	16	6,5	●	
	020	20	8,5		●
	025	25	10,5		●
	032	32	13,5		●
	040	40	13,5		●
	050	50	17,0		●
	063	63	17,0		●
	080	80	21,0		●
	100	100	21,0		●
	125	125	27,0		●

**Ordering Code (example):**

FIBROELAST® Hollow Round Section	=	2541.
Hardness 70 Shore A	=	4.
d1 = 40 mm	=	040
Order No	=	2541.4.040


**Material:**  
Polyester-based polyurethane  
Hardness 70 Shore A

**Colour:**  
White

**Note:**  
FIBROELAST® hollow round sections can also be used as springs. See page F58.

**Physical properties:**

Shore hardness A	70
100% modulus of elasticity (MN/m <sup>2</sup> )	3,0
300% modulus of elasticity (MN/m <sup>2</sup> )	6,0
Tensile strength (MN/m <sup>2</sup> )	28
Elongation (%)	550
Tear resistance (kN/m)	58
Permanent set (%) 70°C	45
Rebound elasticity (%)	55
Maximum deformation (%)	40




# FIBRO

2450.

## Shock Absorbing Washers


2450.



2450.

d <sub>1</sub>	d <sub>2</sub>	s
6,4	16	3
10,5	15	4
11	17	3
13	19	4
8,5	20	3
14	23	4
15,5	23	4
12	24	5
10,5	25	4
13	25	4
14	26	5
17	26	4
18	27	4
22	28	6
21	30	5
13,5	32	4
25	32	6
18	32	7
23,5	34	4
21	35	7
26	35	6
17	38	5
21	38	6
13,5	40	5
32	40	6
27	41	7
31	42	6
37	46	6
32	49	8
17	50	6
26	50	6
37	53	8
32	60	10
17	63	6
37	65	10
42	70	10
21	80	10
21	100	10
27	125	10

### Mounting Example:



### Execution:

2450.6. (90 Shore A) available ex stock.  
80 and 95 Shore A available upon request.

### Ordering Code (example):

Shock Absorbing Washer	= 2450.	Shore A	80 = .5
Shore A hardness of 90 = 6.	= 6.		90 = .6
d <sub>1</sub> = 21 mm	= 21.		95 = .7
d <sub>2</sub> = 80 mm	= 080.		
s = 10 mm	= 10		
Order No	= 2450.6.21.080.10		

A large, empty rectangular box with rounded corners, occupying most of the page. It is intended for drawing or writing.



## Recommendations for Blanking, Forming and Embossing operations with FIBROFLEX® Elastomer

Blanking, forming and embossing with FIBROFLEX® Tooling Elastomer holds quite particular attraction for small to medium batches where, in comparison with conventional tooling, time and cost can be saved in the toolroom.

Conventional dies always depend on the highly accurate relationship between punch and matrix. This does not apply to elastomer dies. Only one part – punch or matrix – will be required. The “opposite member” is provided by the elastomer cushion. This means that elastomer dies are usually made very quickly and therefore cost less. Moreover they afford great flexibility in regard of component modification at a later stage.

Whereas the foregoing considerations left the choice of an alternative solution, presswork with surface-coated or surface-refined material usually does not: with any operational blemishes firmly ruled out, more often than not the “soft touch” of a FIBROFLEX® die is the only answer.

### **FIBROFLEX® Blanking Dies**

In the actual working cycle of an elastomer blanking die, the ram force is initially absorbed by the resistance of the deforming elastomer cushion. As the limit of deformability is reached, shearing and stock breakaway must have taken place. As a general rule it can be stated that stock of high ductility has a detrimental effect on elastomer blanking. The brittle materials on the other hand, such as spring steels, lamination quality strip and certain aluminium alloys are blanked in elastomer dies on quite a large scale. Soft materials like deep drawing steel etc. are unsuitable for the process.

Steel stock of up to 2–2,5 mm thickness can today be handled on FIBROFLEX® blanking dies, while highly accurate blanks of intricate contour can be processed from thin sheet of 0,2 to 0,01 mm thickness. It is here that the inherently uniform clamping pressure of the elastomer cushion proves its beneficial influence – as vindicated by achievable part tolerances of  $\pm 0,01$  mm.

### **Metal Forming with FIBROFLEX®**

Projects of metal forming with FIBROFLEX® must always be based on the rule that an elastomer can be displaced but cannot be compressed. Consequently it is of paramount importance to ensure that sufficient space is provided in an elastomer forming die for the accommodation of the displaced FIBROFLEX®.

### **Combination Blanking, Forming and Embossing Die**

The FIBROFLEX® application examples of figs. 1–4 show clearly how various press work can be done at relatively low tooling cost, often even in combined operations. The FIBROFLEX® pads as well as the interchangeable die members items 3–7 require no fixing. They are simply slid into position according to their operational sequence.

Item 5, a thin sheet of 95 Shore A FIBROFLEX®, is intended as a wear part – to be replaced when worn out.

### **Press Selection**

Due to the normally somewhat greater bulk of elastomer dies, the availability of ample die space in the press has to be assured.

Hydraulic presses with their characteristic slow pressure rise are eminently suitable for elastomer tooling because this feature matches the somewhat delayed deformation behaviour of FIBROFLEX®.


For the same reason, mechanical presses may give a certain amount of trouble because of overloading.

Since no demands need be made on press accuracy, older machines can often be put to good use again with FIBROFLEX® tooling.

Provided applications follow these general guide lines, FIBROFLEX® Tooling Elastomer will prove its enormous resilience time and again – giving shape to workpieces without losing its own.

# Application Examples of Forming Operations with FIBROFLEX® Elastomers

Fig. 5



## Vee-Bending


One of the easiest elastomer-forming operations is that of Vee-bending off a solid punch and into a die cushion of stacked FIBROFLEX® pads.

The necessary penetration of the punch and the amount of over-bending depend on the thickness, hardness and type of the material – and furthermore on the bending radius, the length of the free legs on the piece part, and lastly on the Shore hardness of the cushion.

Applicable to all kinds of bending operations is the general rule: the smaller the bending radius, the less will be the spring-back of the bend and the shallower is the required penetration of the punch.

Especially with larger batch quantities it is advisable to ensure all-round retention of the stacked elastomer cushion; it also pays to make punch and cushion identical in length.

Fig. 6



## Bending of Vee- and U-Shapes

Bending of Vee- and U-shapes can be achieved either with stacked FIBROFLEX® pads of different hardness (Fig. 5), or with the aid of solid and hollow FIBROFLEX® Sections. These may consist of squares, channels or triangular sections.


Where solid sections or sheet is used as a cushion, wear of the elastomer material can be reduced through creation of an additional displacement space at the bottom of the cushion retainer box, similar to Fig. 11, where gib inserts are placed along the corners.

Hollow cushions, as well as those of a channel configuration, exhibit greater die life and are therefore the preferred choice for bending operations.

In the case of a U-shaped bend with straight bottom it may be advisable to insert a packing of 3–5 mm thickness, and of the same width as the flat bottom of the bend, underneath the cushion. This measure increases the forming pressure and helps to achieve a flat bottom on the workpiece.

The punch should be relieved on both sides in order to avail compensation possibilities for springback.

Fig. 7



## U-Bends with large radius

U-bends with a large bottom radius are difficult to accomplish. Punch penetration must of need be large; springback can be quite considerable.


In order to achieve good results, the use of hollow FIBROFLEX® sections or of channels becomes almost mandatory. This is illustrated in Figs. 7 and 12. Another alternative consists of machined form cushions in accordance with Fig. 13.

The hollow space of the channel-shaped cushion has the effect of increasing the horizontal pressure component in the die; this also holds true for hollow die cushions.

In all cases is it necessary to ensure that the cushion retainer box is sufficiently rigid.


## Application Examples of Forming Operations with FIBROFLEX® Elastomers

Fig. 8



FIBROFLEX® Triangular Sections are shaped to fit into the existing forming grooves of bending brake dies, thus eliminating die changes and/or the provision of a die cushion retainer box as required with square cushion configurations.


Fig. 9



Depending on stock specifications the bending of a channel section may either be done off a Vee-shaped punch as a voluntary choice – or it may become an absolute necessity.


Two operational sequences are required, and a goose-necked punch configuration is essential.

Fig. 10




Displacement possible:  
 $a_1 = 50-60\%$  of  $a$   
 $b_1 = 50-60\%$  of  $b$

Fig. 11




Displacement possible:  
 $a_1 = 40-50\%$  of  $a$   
 $b_1 = 50-60\%$  of  $b$

Fig. 12



Displacement possible:  
 $a_1 = 50-60\%$  of  $a$   
 $b_1 = 60-70\%$  of  $b$

Fig. 13



Displacement possible:  
 $b_1 = 60-70\%$  of  $b$

A large, empty rectangular area with rounded corners, intended for drawing or writing. It occupies the majority of the page below the header and above the footer.



# Blanking and forming with FIBROFLEX® - Elastomers

## Blanking and forming with FIBROFLEX®-Elastomers

### Description

FIBROFLEX® forming materials for blanking, embossing and forming are eminently suitable for use in small and medium series production. The main advantage is the reduction in tooling costs compared with traditional production methods.

This means that, even with considerable workpiece changes or with prototypes, you can respond quickly to changing market requirements and delivery times.

You can avoid scratching or damaging the increasingly common coated and highly polished sheet metals by using the gentle touch of elastomers for the forming process.

### Forming with FIBROFLEX®

When forming using elastomers, always remember the golden rule: whatever the extent of the deformation, the elastic FIBROFLEX® forming material remains constant, i.e. it can be displaced, but not compressed. The design must allow the elastomer to “flow” into a relief gap – that is the secret of success.

### Choice of Machine


When FIBROFLEX® matrices are used for blanking, embossing and forming the machine must be able to accommodate the displacement.

Hydraulic presses are preferable to mechanical presses because of their gradual pressure build-up which suits the characteristics of the FIBROFLEX® forming material as it changes shape.

If a mechanical press is overloaded as it approaches bottom dead centre (which is also the cutting point), there is a risk of the press being damaged.

With FIBROFLEX® the machine is not subjected to any stresses, so even old machines can be used.

**FIBROFLEX® Forming tool blanking – drawing – embossing**



**Combined blanking – embossing – punching**


The workpiece is completed at one pass. The shape is determined by the combined blanking, hole cutting and embossing matrix blank holder punch, without a reverse shape mould on the cushion side.

The thrust plate in the carrier produces a concentration of pressure which produces a better result in the active tool range. The thrust plate also provides the necessary compensation for constant volume.

When producing workpieces of a different shape, only the tool elements in the lower section which produce the shape have to be exchanged.



FIBROFLEX® Forming tool dishing



**Bulging a pot**


For flaring and bulging operations we recommend the use of FIBROFLEX® concave profiles wherever possible.

The wedge shape of the elastomer and the shape of the pressure and counter pressure punches both encourage the elastomer to deform in the required direction.

For bulging work it is worth taking into account the basic principle for FIBROFLEX®, namely that it maintains a constant volume. (Displaced volume equals bulging volume – see also description on page 2).



**FIBROFLEX®  
Universal Blanking and Forming Carrier**



**FIBROFLEX® blanking matrices**

When blanking with Elastomers, the workpiece materials, in contrast to the traditional blanking of workpiece materials, are subjected to their elastic limits, beyond which the material breaks.

The thickness of sheet steel which can be cut using FIBROFLEX® is currently up to 2.5 mm.


The even clamping pressure which is excellent for pressing also means that parts with intricate contours can be manufactured.

It is possible to achieve workpiece accuracy of  $\pm 0,01$  mm.

During the blanking process the press pressure first deforms the elastomer. As soon as the elastomer reaches the limits of its deformation the workpiece is cut.

The less the stretch of the sheet metal, the easier it can be cut using the elastomer blanking process. Spring band steels, electric sheets and sheet aluminium all cut well using this process. Deep-drawing sheet steel is unsuitable for the elastomer blanking process.

**FIBROFLEX®**  
Forming tool drawing – embossing




**Drawing and embossing**

The limits for flaring and bulging depend on the workpiece material, its thickness and hardness and also the height of the FIBROFLEX® cushion.

Maximum permissible deformation of the FIBROFLEX® cushion:

- 80 Shore A – 35%
- 90 Shore A – 30%
- 95 Shore A – 25%

## FIBROFLEX® Forming tool for flaring pipes



### Flaring pipes

When flaring using FIBROFLEX®, split cheeks with a conical external surround are required to allow the workpiece to be released.

Depending on wall thickness, flaring ratios of 1.2 can be achieved. Above a workpiece diameter-to-length ratio of 2 : 1 it is advisable to use concave cushions with bolt guides.



A large, empty rectangular box with rounded corners, occupying most of the page. It is intended for drawing or writing.